

Perfex™ Hanging Signframe Kits

1. If mounting on drywall or hollow walls, pre-drill a 3/16" hole and insert Molly Anchors provided.
2. Screw bottom wall mount brackets to wall (fig. A).
3. Screw top wall mount brackets to wall (fig. B-1) or hammer nails into wall to secure (fig. B-2).
4. If frame is being hung from ceiling, insert hanging clips and use wire to hang (fig. C).

Applicable Products:

PX1, PX2, PX3, PX4,
PX5, PX6

