

W-01-C

Fabric counter assembly

Step 1. Attach the base with 5_16_ 18 x2 stud.

Step 2. Attach the Top with 5_16_ 18x 1.25 stud.

Step 3. Push the fabric into the groove on the Base and on the Top.

- When working with fabric use gloves or clean hands and keep fabric away from dirty surfaces.

QTY	CODE	DESCRIPTION
6	5-16-18 WING NUT	5/16-18 WING NUT
3	5_16_ 18 X 1.25 STUD	5/16-18 x 1.25" STEEL STUD
3	5_16_ 18X2 STUD	5/16-18 X 2" STEEL STUD
2	G-W-01-FAB	PILLAR FABRIC GRAPHIC
1	TRI30-COUNTER	900MM LENGTH OF TRILOK TRUSS
1	W-01-C-B	PILLAR BASE
1	W-01-C-T	PILLAR TOP

