MONDO SET UP INSTRUCTIONS





2.Unfold the base



3.Fix the bottom connection-unit with orientation dowelling.



4.Assemble the upper connection-unit, unfolded-base and section(as step-3) together.



5. Fix the orientation nut against base.



6.Detach the branches of the vertical-pole.



7.Make sure that the branches of the verticalpole can be fixed at the base.



8.Connect the horizontal-pole and verticalpole with the upper-snail.



