

8 Foot Demo

Booth Setup:

- 1) Insert pipes with buttons (B, C, D) into fitting with button holes (X).
Make sure the button snaps into button hole securely.
- 2) Position bottom frame into a rectangle with snaps facing out.
- 3) Snap skirt on, starting at one end.
- 4) Clip counter legs to frame. Attach counter support cross braces.
- 7) Align counters over Hook & Loop and press down firmly to secure.
- 8) Place optional undercounter shelves on bottom counter leg braces.

