

Instructions

For hollow wall thickness 0.125" to 0.500" thick

1. Drill 7/16" dia hole into wall at desired locations
2. Remove screw from anchor
3. Tap-in anchor with hammer into drilled hole until anchor is flush with wall
4. Turn screw into anchor until anchor flairs open and locks onto wall (see photo below).
Screw will tighten once anchor locks onto wall.
5. Remove screw from anchor
6. Position item to be hung onto wall
7. Fasten item to wall by re-installing screw thru item into anchor

Back side view of expanded anchor



Expanding Hollow Wall Anchor
P/N: HWA