

Perfex™ Sky Structure

1. Align frame with the mounted angle clip to the other frame with the slotted holes, making sure the the open slot on both frames match. Screw both frames together using a screwdriver with the screws provided (fig. A).
2. Use Jack Chain to hang from the hook on the bracket (fig. B).

