

10' TUBO WAVE



1. Carry bag with stand



2. Take out the frame from the case, then connect the tube one by one with the same shape



3. Lock the feet



4. The completed frame should look like this



5. Cover the frame



6. Close the zipper