









ToolCart MX™ Assembly Instructions

Box Contents

| Image | Description | 4x6 | 2x6 | Image | Description | 4x6 | 2x6 | Tools Needed  |
|--|----------------------|-----|-----|---|-------------------------|-----|-----|--|
|  | Shelf (top & bottom) | 2 | 2 |  | Screw 1/4-20 x 2" | 3 | 3 | Phillips Screwdriver |
| | PegBoard Panels | 2 | 2 |  | Acorn Nut 1/4-20 | 23 | 15 | 7/16" Wrench |
|  | Caster | 2 | 2 |  | Shelf Screw 1/4-20 x 1" | 20 | 12 | 3/4" Wrench |
|  | Lockable Caster | 2 | 2 |  | Spacer and Gluedots | 26 | 18 | |

ToolCart MX™
P/N: HPBTC.XXXX.X



Assembly:



1. Adhere GlueDots to spacers.



2. Place 1" screws through the pre-punched holes located on the center and bottom shelves. Attach the spacers with GlueDots to the outside of the shelves.

Helpful Hint!
Remove excess glue from the screw thread.
This will allow the acorn nuts to be easily tightened.

ToolCart MX™ Assembly Instructions

Assembly Continued



3. Attach the pegboard to the larger, bottom shelf. Line the shelf up with the bottom row of holes on the pegboard. Secure the pegboard to the shelf using acorn nuts. Acorn nuts should be on the outside of the pegboard.



4. Repeat step 3 — Attach the second pegboard to the opposite side of the shelf.

ToolCart MX™ Assembly Instructions

Assembly Continued



5. Using the Gludots, attach two of the 3/4" spacers together. Place one 2" screw through the center hole at the top of one pegboard panel. Repeat this step and add spacers to first and last peg hole on the top row.



6. Next, place the double spacer over the screw and bring both pegboards together. The 2" screw should go through the center hole of the pegboard on the opposite side. Secure the pegboards together using an acorn nut.

Helpful Hint!

Do not tighten the acorn nuts. This will make installing the center shelf easier.

ToolCart MX™ Assembly Instructions

Assembly Continued



7. Count down from the top of the pegboard unit, 28 holes, for the location of the center shelf.



8. Secure the center shelf to the pegboard using acorn nuts.

ToolCart MX™ Assembly Instructions

Assembly Continued



9. Attach casters (wheels).