

Step 1

Insert the notch on the center of each of the Feet (4) to the receptacles on the bottom of the Base (1).



Step 2

Slide the inside of the Buckle (4a) into the groove on each side of the Base (1). Press the top of the Buckle (4) down to secure the Feet (4) into place.



Step 3

Connect the Shock Cord Pole (3) sections together and insert the spring end of the Shock Corded Pole (3) into the pole receptacle on the Base (1).



Step 4

Stand facing the back of the Base and gently pull the Banner Rail (2) upwards. Connect the back of the Banner Rail (2) into the top of the Shock Cord Pole (3).

Repeat step 4 to display a 2nd banner on the other side.

