

**Congratulations on the purchase of your Outdoor Retractor™ Banner Display.**

## Owner's Manual

Includes:

Parts List

Assembly Instructions

Disassembly Instructions

Care Instructions

Storage Instructions

Warranty Information


Please read all of the information carefully and contact your distributor or supplier with any issues.



## Parts List

**Important:** Before you begin please count and inspect all pieces.

- 1 - Base with (2) graphic cartridges and banners (A)
- 1 - Top Assembly (B)
- 2 - Telescoping Poles (C)
- 1 - Carry Case (D)




## Assembly Instructions



### Step 1 (Pole Assembly)

Insert poles (C) into collars on base (A) as shown. Tighten knobs.




### Step 2 (Suspension Assembly)

Unscrew knobs from the top assembly (B). Place assembly on top of poles as shown and screw knobs back on (both poles). Make sure that the black knobs are on the top.



### Step 3 (Banner Attachment Assembly)

Pull banners up out of the graphic cartridges, and set the banner top bars on hooks. Hold down locking bracket and tighten down black knobs.



### Step 4 (Extended Pole Assembly)

Pull up on both poles (C) until the tabs lock into place. *\*This may require two people.*

## Assembly Instructions (cont.)



### Step 5 (Optional)

Fill with water or sand for added stability.

## Disassembly Instructions




### Step 1

Press tabs in on both poles (C), and slide poles down.



### Step 2

Loosen black knobs, and remove banner top bar from the hooks, one at a time. Slowly lower banners back into graphic cartridges.



### Step 3

Unscrew knobs from the top assembly (B) and remove from poles (C).



### Step 4

Loosen knobs at the base of the poles (C), remove poles from base (A) and empty out water or sand from base.

## Storage Instructions



Store all components in soft carry case (D), in a cool, dry place.

## Care Instructions

Spot clean with a damp cloth.

## Warranty Information

All products are designed to provide the user with a cost-effective and durable product. Standard warranty is a 'one year parts and labor' warranty which warrants product against defects in material and workmanship. It does not cover damage due to accidents, abuse, or normal wear and tear. Products found to be defective will be replaced or repaired at factory's discretion.