


Showstopper™ Concession Stand

Assembly Instructions




Step 1 - Unfold canopy frame (Fig.1) by pulling poles outward from center. Best to perform this step with two people working from opposite sides from each other.




Step 2 - Extend legs of the canopy by pulling out the leg until the spring button (Fig.2) snaps into position.



Step 3 - Unfold frame (Fig.3) for counter to form horse-shoe shape.




Step 4 - Insert bottom of the canopy legs into the U-shaped brackets (Fig.4) located at the bottom of the counter frame.




Step 5 - Insert large screws through the canopy legs & into the anchor bracket (Fig.5) located at the top of the counter frame.



Step 6 - Locate lower shelf units and extend legs by rotating until they make contact with stop (Fig.6).




Step 7 - Position shelves into counter frame as shown (Fig.7).




Step 8 - Locate counter-tops (Fig.8). Countertops do not have folding legs on the bottom side.



Step 9 - Position counter-tops onto frame as shown (Fig.9) Two longer shelves are for each end.



Step 10 - Locate 3 'X' shaped scissor support brackets & position onto counter frame (Fig.10).



Step 11 - Attach support bracket to the counter frame with one small screw to the bracket (Fig.11).



Step 12 - Attach skirt to the counter frame with Velcro® tabs located on the back side of the skirt & the brackets at top & bottom of the frame (Fig.12).