


Instructions on how to set up Duro Deck

Connecting riser and deck

First you start off by pulling the riser out of the box. It will look like this when its unwrapped. You will be able to see a few inches of black plastic guides. Those could be on the bottom or top it does not matter. Then open the riser to the fullest length, when everything is open properly then close it about 6" and lay the deck on top. Once the deck is on top place a bit of pressure on top of the deck till it locks with the riser.



Connecting multiple decks

On 2 side of the Duro Deck you will see there is 2 sets of opening locking lips vises, on the corner of each Duro deck there is a Allen wrench. Covered with a peace of carpet. On the stage deck there is a groove that go's all around the deck, the locking lips slide right into the groove. Then you get the Allen wrench and screw the vise down and that will lock your deck together.



Attaching skirts

Each and every Skirt comes with a small roll of Hook & Loop and 4 clips. The skirt has 4 gap in between the Hook & Loop and the material, the clips slide in there. When all 4 clips are in the skirt place the first clip by the groove of the stage and the top of the stage, and apply a little bit of pressure for it to stay on the deck. When starting the next skirt, start with Hook & Loop on the end of the skirt.

