


Product Specifications

Viewable Graphic Size: 15' side: 175" w x 85.75" h
10' ends 116.5" w x 85.75" h

Graphic Finishing: Dye Sublimation
Graphic Template Available

Product Parts

- 1 - Frame
- 2 - Canopy
- 3 - Dust Cover




Set-Up

Step 1


Remove the Frame (1) from the Dust Cover (3) and place it at your desired location.

In tandem with another person, separate the legs of the tent until they are extended a full arms length.




Step 2

Unfold your Canopy (2) and drape over the tent's Frame (1). Attach the Canopy (2) by connecting the loop strips on the canopy corners with the hook strips on the frame's four legs. Position the canopy's apex with the center pole of the Frame (1).




Step 3

Stand diagonal to each other and separate the frames legs. The frame will open a little at a time so alternate ends until the Frame (1) no longer expands.



Step 4

Lift the expanding section of the frame upwards until the four sliding connectors lock into place on the frame's legs.




Push down red button while lifting connector and release to lock into desired hole placement.

Set-Up Continued...


Step 5

Place your foot on the base of the tent leg as you release and extend the telescoping legs. Raise the tent to your desired height and lock the legs into place.



Step 6



Lift the (2) apexes of the canopy up into place by turning the crank counterclockwise until the canopy is taut.




Secure with Stakes - Sold Separately

Simply drive the stakes through the holes in the feet and into the ground (Option 1) OR Secure by looping rope through the "D" ring located on each tent corner (Option 2).

OPTION 1




OPTION 2





Secure with Ballast - Sold Separately

Simply strap the Ballast to the legs and fill with water or sand.



Storage

Leave Canopy (2) on Frame (1) and Collapse unit. Place provided dust cover over Frame (1) with feet exposed, or place in available Soft Case item # 220080 (Not Included).



Dust cover is for storage only & is not a carry case- It does not cover entire frame.



Soft Case 220080

Store in a cool dry location.

Care

To clean, wipe with damp cloth.

Warranty Information: All products are designed to provide the user with a cost-effective and durable product. Standard warranty is a 'one year parts and labor' warranty which warrants product against defects in material and workmanship. It does not cover damage due to accidents, abuse, or normal wear and tear. Products found to be defective will be replaced or repaired at factory's discretion.