

Product Specifications

Visible Graphic: N/A
Total Graphic Print Size: N/A
Bottom Bleed: N/A
Color: White
Footprint Dimensions: N/A



Product Parts

- 1 - Molded Plastic Connectors
- 2 - Large Bolt with Plastic End
- 3 - Long Bar
- 4 - Short Bar




Assembly



Step 1

Insert end of Long Bar with push button into one end of the Short Bar, securing it in place when the push button clicks into the hole on the Short Bar.



Step 2

Repeat Step 1 with the other Long Bar, inserting it into the opposite side of the Short Bar.



Step 3

Place one of the Molded Plastic Connectors over one of the tent legs that you would like the stabilizing bar to be connected to. The open end of the Molded Plastic Connector should face towards the other tent leg you want the stabilizing bar connected to.



Step 4

Place the remaining Molded Plastic Connector over the other tent leg you want the stabilizing bar to be connected to and have the open end of the Molded Plastic Connector facing the first Molded Plastic Connector you installed onto the tent leg.



Step 5

Insert one end of the stabilizing bar into of the Molded Plastic Connectors.



Step 6

Insert Large Bolts with Plastic End through open hole on Molded Plastic Connector and into the threaded hole on the stabilizing bar and into the threaded hole on the Molded Plastic Connector. Tighten the Large Bolt with Plastic End firmly.

Repeat for other side.

DisAssembly



Step 1

Remove both Large Bolts with Plastic Ends.



Step 2

Remove stabilizing bar from Molded Plastic Connectors.



Step 3

Disassemble stabilizing bar by pressing in push button on the Large Bar and sliding it out of the Short Bar. Repeat for other Large Bar.



Step 4

Remove Molded Plastic Connectors from tent legs.

Storage and Care

Step 1

Wipe clean with a damp cloth. Store in a cool, dry place.