

ASSEMBLED UNIT

AZ1

AZ2 AZ3 AZ4

AZ5 AZ6 AZ7

AZ8

Parts List

- grippers
- left beam 004
- upper post 003
- upper wing
- post trim 008
- lower wing
- lower post 002
- post trim 008
- counter top 013
- L bracket 012
- counter post 009
- fill panel 011
- lower shelf 014
- counter beam 010
- counter post 009
- base plate 001
- left beam 005
- header panels
- 150w light fixture
- 006 upper support
- 005 right beam
- 006 upper support
- 008 post trim
- 007 lower support
- grippers
- 003 upper post
- 007 lower support
- upper wing
- 002 lower post
- 008 post trim
- lower wing
- 004 right beam
- 001 base plate

STEP 1 Base & Post Assembly

1 Attach base plates to posts, using supplied bolts and allen tool. Connect upper post to lower post with supplied thumb-screws. Repeat procedures for second post assembly.

NOTE: Remove this connector before packing

STEP 2 Beam Connections

2 Connect beams and supports together, as shown, using Torx tool (included). Do not over-tighten.

NOTE: Remove connectors from beams before packing

2 supports

upper & lower beams

STEP 3 Beam Attachment

3 Attach beams to posts as shown. Supports with 2 metal strips go vertically in center of structure (see below for locations, line up red arrows of supports with red arrows of beams in upper & lower beams). Secure locks using Torx tool. Be sure magnet is aligned as shown. Snap plastic post trim sections into grooves of posts.

NOTE: Remove connectors from beams before packing

TENSION LOCK OPERATION
PLACE TENSION LOCK INTO GROOVE
INSERT TORX WRENCH AND TURN 1/2 TURN

support locations

metal strips face front

STEP 4 Wing Attachment

4 Connect the panel grippers (8 total) to posts (nylon set screw facing back) and tighten using supplied screwdriver.

Insert panels into grippers and tighten nylon set screws to secure. Do not over-tighten

STEP 5 Header Assembly

5 Connect panel grippers to upper vertical beam (nylon set screw facing back) and tighten. Insert header into grippers and tighten nylon set screws to secure. Do not over-tighten.

Repeat for other header panel sections.

STEP 6 Center Header

6 For units with a center header panel, connect panel grippers to upper vertical beam. Then header into grippers by tilting forward slightly to clear side headers. Tighten nylon set screws to secure. Do not over-tighten.

NOTE: Tilt forward to install between side headers

SIDE VIEW

STEP 7 Light Attachment

7 Raise header a little and attach lights to upper vertical beam as shown. Feed cord between header & beam and drape over back of unit. Replace header.

150w light fixture

STEP 8 Graphic Panels

8 Carefully unpack and unroll magnetic graphic panels and attach to magnet on beams & post trims. Start at top and roll downward, keeping edge aligned with post.

remove graphic from tube

unroll graphic

graphic panel mounted

STEP 9 Fabric Graphic Option

9 FOR FABRIC OPTION: Lay out fabric and orient with graphic facing front and up. Starting in an upper corner, squeeze bead edge of fabric into groove with roller tool (supplied). Continue around edge until all bead is inserted. Graphic can then be straightened by pulling bead within groove as needed.

STEP 10 Counter Assembly

10 Turn counter top upside down (slots facing up) and lock a post into front slot using supplied tool. Insert fill panel into groove in post and slot in top. Lock the other post into the slot. Insert small beam in between posts and slide down onto panel. Lock beam into position. Flip counter assembly over and attach to post as shown, using the L bracket & lock tool.

STEP 11 Counter Shelf

11 Insert the three shelf pins into grooves of counter posts and main unit post as shown on left. Twist pin clockwise to tighten. Be sure all 3 pins are at same height. Drop shelf down onto pins with slots in shelf facing down.

shelf pin

STEP 12 Shelf Option

STEP 13 Monitor Option

NOTE: This bracket can remain attached to LCD for packing & shipping

LCD 20"

PACKING

Main Unit

with 1 Counter

with 2 Counters

Monitor Option

NOTE: Wrap the graphic panels with image facing out, taking care not to damage the magnet tape on the back.

NOTE: Remove connectors and grippers from posts and beams before packing

instructions

left beams (2) 004

right beams (2) 005

post trims (4) 008

upper posts (2) 003

lower posts (2) 002

counter posts (2) 009

fill panel 011

headers & wings

counter beam 010

L bracket 012

lower shelf 014

counter top 013

base plates (2) 001

grippers envelope & tool pouch

graphic panels (3)

lights (2)

instructions

left beams (2) 004

right beams (2) 005

post trims (4) 008

upper posts (2) 003

lower posts (2) 002

counter posts (2) 009

fill panel 011

headers & wings

counter beam 010

L bracket 012

lower shelf 014

counter top 013

base plates (2) 001

grippers envelope & tool pouch

graphic panels (3)

lights (2)

instructions

left beams (2) 004

right beams (2) 005

post trims (4) 008

upper posts (2) 003

lower posts (2) 002

counter posts (2) 009

fill panel 011

headers & wings

counter beam 010

L bracket 012

lower shelf 014

counter top 013

base plates (2) 001

grippers envelope & tool pouch

graphic panels (3)

lights (2)

instructions

left beams (2) 004

right beams (2) 005

post trims (4) 008

upper posts (2) 003

lower posts (2) 002

counter posts (2) 009

fill panel 011

headers & wings

counter beam 010

L bracket 012

lower shelf 014

counter top 013

base plates (2) 001

grippers envelope & tool pouch

graphic panels (3)

lights (2)

instructions

left beams (2) 004

right beams (2) 005

post trims (4) 008

upper posts (2) 003

lower posts (2) 002

counter posts (2) 009

fill panel 011

headers & wings

counter beam 010

L bracket 012

lower shelf 014

counter top 013

base plates (2) 001

grippers envelope & tool pouch

graphic panels (3)

lights (2)