



Set Up Instructions

NAT-INFLATABLE TENT


Step 1: Take the tent out of the box.
CAUTION: To avoid any damages or punctures to the frame, do not drag the tent frame around on the ground.



Step 5: Align and slide the nozzle onto the air pump hose. Twist to lock into place.




Step 6: Turn the pump on and place the nozzle over the air valve until it completely drops down over the valve and begins to inflate the frame.



REVERSABLE PUMP:
Insert on one end to inflate tent, remove hose and place into other end to deflate tent.

Step 3: Find the zipper head on the tent and attach the graphic to the frame.



Step 7: Around 90% of air fill lift top upward to pop canopy into place. Complete filling frame to 100%.

Step 4: Completely zip the graphic onto the frame.

