

Instructions For:

Tripod Banner Display

Product Specifications

Visible Graphic: 24" W x 60" H

Total Graphic Print Size: 24" W x 60" H

Requires #2 Grommets

Foot Print Dimensions: 25" x 29"

Product Parts

1 - Tripod Base

2 - Arms



Step 1

Remove all parts from the bag. Place the unit on the ground/
work surface


Step 2

Gently expand the Tripod Base (1) until it can stand on its own.



Step 3

Insert Arms (2) into the Tripod Base (1) as shown.



Step 4

Attach the banner by hooking the grommets to the coralating
grommet hooks on the ends of both Arms (2) and then to the
grommet hoods on the front legs of the Tripod Base (1).

