
## Hanging 3D Displays - Hanging Square, Hanging Triangle

Assembly Instructions


R2.031317

## **ASSEMBLY HARDWARE**




A. 3D Connector(s)
D. Steel Rope(s)

B. 60° Connector(s) E. Aluminum Pole C. Carabiner Snap Hook



## **ASSEMBLY**



- 1. Assemble the Aluminum poles (E) and connectors to create the display. The Hanging Square will use the 3D Connector (A) and the Hanging Triangle will use the 60° Connector (B). Slip the bottom of all top connectors through one of the looped ends of the Steel Rope (D).
- If the print is a single-reverse, then assemble Aluminum poles (E) with the hook-and-loop adhesive so they will line up with the print. The hook-and-loop adhesive on the Aluminum poles (E) should also be angled inward slightly to make the print taut.
- 2. Attach print depending on layout option:
- Single-reverse Slip print over the top of the frame. Wrap the tabs on the top of the print over the top of the frame and attach to the hook-and-loop adhesive. Pull print taut and wrap the bottom print tabs under the frame and attach to the hook and loop adhesive.
- Double-sided Flip frame upside down and slip the print on upside down. Flip frame and print over and pull the print upwards. Wrap the outside of the print over the frame and attach to the inside of the print using the hook-and-loop adhesive. Make sure the steel rope (D) is not tucked inside the print.
- 3. Feed the non-attached loops of Steel Rope (D) through the Carabiner Snap Hook (C) and attach to a suitable mounting location.