



# SACAGAWEA DESIGNS



10'

10'

WHEN DISASSEMBLING ALUMINUM EXTRUSION, TIGHTEN ALL  
SETSCREWS AND LOCKS TO PREVENT LOSS DURING SHIPPING

# SACAGAWEA

DESIGNS

**Using You Set-up Instructions:**


The Visionary Designs Set-up Instructions for Sacagawea displays are created specifically for your configuration. They are laid out sequentially, including an exploded view of the entire display and a logical series of detailed steps for assembly. We encourage you to study the instructions **before** attempting to assemble your exhibit.

**THIS IS VERY IMPORTANT!**

Each page reminds you to tighten the setscrews after disassembling your exhibit to prevent loss of the locks and setscrews (see below in red).

**Cleaning & Packing Your Display:**

- 1) Use care when cleaning aluminum extrusions or acrylic inserts. Use only non-abrasive cleaners.
- 2) When cleaning laminate inserts or counter tops, use mild cleansers and a soft material such as cotton.
- 3) Keep all display components away from extreme heat and long exposure to sunlight to avoid warping and fading.
- 4) Retain all packing materials. It will make re-packing much easier and will reduce the likelihood of shipping damage.



**Detail B:** Each extrusion contains a numbered label that corresponds to set-up instructions. The label is located within a groove of the extrusion (when possible). Visionary Design labels contain Black numbers unless otherwise specified.

Horizontal Connection



**Detail C:** A rectangular connection bar with plastic T Knobs is inserted between two horizontal extrusions joined end-to-end. Turn the knobs clockwise to tighten. Do Not Overtighten.

Hex Key Tool



Most visionary design exhibits can be assembled with the supplied Hex Key Tool. Occasionally, a flat head screwdriver may be required.

Typical Connection



**Detail A:** Most horizontal extrusion connections have a patented expandable lock. This lock inserts into the groove of an opposing extrusion. Tightening the lock with the Hex Key Tool expands the lock and creates a strong positive connection.

Typical Connection



Base Plate Connection



**Detail D:** Attach vertical extrusions to base plates with supplied bolts inserted through the hole in the plate. Be careful not to strip the thread.

Vertical Connection



**Detail E:** A square connection bar with plastic T Knobs is inserted between two vertical extrusions joined end-to-end. Turn the knobs clockwise to tighten. Do Not Overtighten.

Corner Connection




**Detail F:** Plastic Star Knobs are used to tighten locks where horizontal extrusions connect with vertical extrusions. Turn the knobs clockwise to tighten. Turn counter-clockwise to loosen, but do not remove knob. Do Not Overtighten.


**WHEN DISASSEMBLING ALUMINUM EXTRUSION, TIGHTEN ALL SETSCREWS AND LOCKS TO PREVENT LOSS DURING SHIPPING**

Item	Qty.	Description
1	2	Base Plate w/ 1 Hole
1a	1	Base Plate w/ 2 Holes
2	1	42" Lower Square Vertical Extrusion
3	1	42" Upper Square Vertical Extrusion
4	1	42" Lower Square Vertical Extrusion
5	1	42" Upper Square Vertical Extrusion
6	1	42" Lower Square Vertical Extrusion
7	1	32" Upper Square Vertical Extrusion
8	1	42" Lower Square Vertical Extrusion
9	1	42" Upper Square Vertical Extrusion
10/10a	1/1	47" Horizontal Extrusion
11	1	38.25" Horizontal Extrusion
12	1	40.9826" Curved Extrusion
13	1	4" Stabilizing Extrusion

- Steps:
- 1) Attach vertical extrusions [2,4,6,8] to base plates [1,1a].
  - 2) Attach upper vertical extrusions [3,5,7,9] to lower extrusions [2,4,6,8] using connection bar [b].
  - 4) Connect stabilizing bar [13] between verticals [5,7], refer to detail.
  - 5) Attach horizontal extrusions [10,10a,11,12] between vertical assemblies as shown.
  - 6) Apply graphic to back of assembled backwall.





STAR indicates location of knobs on BACKSIDE of unit.



Turn Knob Clockwise to Tighten Lock

\*\*Do not over tighten Knobs.\*\*

GREEN STAR indicates location of connection lock with knob.




Graphic Attachment  
Apply graphic to back of assembled backwall.

Slide Connection Bar between Extrusions and tighten Knobs to secure.


WHEN DISASSEMBLING ALUMINUM EXTRUSION, TIGHTEN ALL SETSCREWS AND LOCKS TO PREVENT LOSS DURING SHIPPING

- Steps:
- 1) Attach assembled header frame to top of backwall as shown.
  - 2) Apply graphic to velcro on back of header frame.
  - 3) Attach lights to header frame and backwall as shown.
  - 4) Attach wings to backwall with A10 clamps.
  - 5) Attach literature racks to backwall as shown.
  - 6) Attach assembled counter support [18/19] to vertical where indicated.
  - 7) Attach support leg [18a] to counter support [18/19].
  - 8) Attach flange plate [19a] to top of curved extrusion [19] as shown.
  - 9) Attach counter top to support, see [counter top attachment](#) detail.
  - 10) Attach monitor mount to connectors as shown.


Item	Description
14	9.2856" Vertical extrusion
15	9.2856" Vertical extrusion
16	43.66" Curved Horizontal Extrusion
17	30.2" Curved Extrusion
17a	Leg Support
18	12.184" Horizontal Extrusion
18a	Flange Plate




\* Monitor Mount Attachment




A10 Clamp Detail



Literature Rack Attachment



Counter Top Attachment







WHEN DISASSEMBLING ALUMINUM EXTRUSION, TIGHTEN ALL SETSCREWS AND LOCKS TO PREVENT LOSS DURING SHIPPING




Item	Qty	Description
19	4	38" Vertical Extrusion
20/20a	2/2	12" Horizontal Extrusion
21	2	25" Horizontal Extrusion

- Steps
- 1) Attach horizontal extrusions [20 and 20a] between vertical extrusions [19], placing inserts between horizontals.
  - 2) Attach curved horizontal extrusions [21] between vertical extrusions [19], placing insert between curved horizontals.
  - 3) Place shelf on top of lip of extrusions.
  - 4) Set counter top on assembled base.




WHEN DISASSEMBLING ALUMINUM EXTRUSION, TIGHTEN ALL SETSCREWS AND LOCKS TO PREVENT LOSS DURING SHIPPING


Top View




Level 1



Level 2



Level 3



Level 4


Graphics

Setup Hardware &  
Literature Pockets


Halogen Lights

WHEN DISASSEMBLING ALUMINUM EXTRUSION, TIGHTEN ALL  
SETSCREWS AND LOCKS TO PREVENT LOSS DURING SHIPPING


Top View




Level 1



Level 2



Level 3



Level 4

WHEN DISASSEMBLING ALUMINUM EXTRUSION, TIGHTEN ALL SETSCREWS AND LOCKS TO PREVENT LOSS DURING SHIPPING