





Part Number	Qty	Description
13	1	48.5"h Lower Curved Extrusion
14	1	48.5"h Upper Curved Extrusion
15	1	48.5"h Lower Curved Extrusion
16	1	48.5"h Upper Curved Extrusion
17a/17b	1/1	44"w Lower Horizontal Extrusion
18a/18b	1/1	44"w Upper Horizontal Extrusion
19	1	23"w Lower Horizontal Extrusion
20	1	23"w Upper Horizontal Extrusion
21	1	Backwall Support Leg Extrusion



- Steps
- 1) Connect upper and lower vertical extrusions together [13 to 14 and 15 to 16].
 - 2) Connect horizontal extrusions together [17a to 17b and 18a to 18b].
 - 3) Attach horizontal assemblies [17a/17b and 18a/18b] between vertical assemblies [5/6 and 13/14].
 - 4) Attach horizontal extrusions [19 and 20] between vertical assemblies [13/14 and 15/16].
 - 5) Attach support leg extrusions [21] to back of verticals [15], see leg attachment detail.





WHEN DISASSEMBLING ALUMINUM EXTRUSION, TIGHTEN ALL SETSCREWS AND LOCKS TO PREVENT LOSS DURING SHIPPING

Part Number	Qty	Description
22	2	Base Plate
23	2	37.6" h Curved Vertical Extrusion
23a	2	Oval Flange Plate
24	2	18.5" w Horizontal Extrusion
25	2	15.69" w Horizontal Extrusion


Steps

- 1) Attach curved vertical [23] to base plate [22], see Base Plate Attachment detail.
- 2) Attach horizontal extrusions [24 and 25] between curved verticals [23] and backwall verticals [3 and 13] where indicated.
- 3) Attach flange plate to top of verticals [23] as shown.
- 4) Place counter tops on assembled counter base, see Counter Attachment detail.



Counter Top Attachment

Insert screws located on underside of counter into holes on flange plate and secure with wing nuts.




WHEN DISASSEMBLING ALUMINUM EXTRUSION, TIGHTEN ALL SETSCREWS AND LOCKS TO PREVENT LOSS DURING SHIPPING

Part Number	Qty	Description
26	1	37.5"h Vertical Extrusion
27	1	37.5"h Corner Extrusion
28	1	37.5"h Corner Extrusion
29	1	37.5"h Vertical Extrusion
30/30a	6	11"w Horizontal Extrusion
31	2	24.875"w Horizontal Extrusion




Steps

- 1) Attach horizontal extrusions [30 and 30a] between vertical extrusions [26&27 and 28&29], see Top View for extrusion orientation.
- 2) Attach curved horizontal extrusions [31] between corner extrusions [27 and 28], placing insert between curved horizontals.



Steps (Cont'd):


- 3) Place hooks onto horizontal extrusions where indicated, see Hook Attachment detail.
- 4) Set shelf atop hooks.
- 5) Set counter top atop assembled base.




WHEN DISASSEMBLING ALUMINUM EXTRUSION, TIGHTEN ALL SETSCREWS AND LOCKS TO PREVENT LOSS DURING SHIPPING

Top View of Each Level


Backwall Components




Level 1 (Bottom)






Level 2



Level 3




Level 4




WHEN DISASSEMBLING ALUMINUM EXTRUSION, TIGHTEN ALL SETSCREWS AND LOCKS TO PREVENT LOSS DURING SHIPPING

Top View of Each Level


Backwall Components






Level 1 (Bottom)



Level 2




Level 3



WHEN DISASSEMBLING ALUMINUM EXTRUSION, TIGHTEN ALL SETSCREWS AND LOCKS TO PREVENT LOSS DURING SHIPPING

Top View of Each Level


Pedestal Components



WHEN DISASSEMBLING ALUMINUM EXTRUSION, TIGHTEN ALL SETSCREWS AND LOCKS TO PREVENT LOSS DURING SHIPPING

Top View of Each Level

Pedestal Components



WHEN DISASSEMBLING ALUMINUM EXTRUSION, TIGHTEN ALL SETSCREWS AND LOCKS TO PREVENT LOSS DURING SHIPPING